

Uptmate Technology Co., LTD

USP (Uptmate Scheduling Program)

User Manual

Software Version: V1.0 Beta

Revision

Item	Issues Dates	Description	Actions	Date
1	2010/01/27	First Release Edition		
2	2010/2/2	Add Remark		
3				
4				
5				
6				
7				

Uptmate Technology Co., LTD

幸楷科技股份有限公司

USP

(*Uptmate* Scheduling Program)

User Manual

Software Version: V1.0 Beta

Department	RD/PM
Prepared by	
Approved by	

Copyright

This technical document, including photographs and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the materials contained herein, may be reproduced without written consent of the company or their respective owners.

Uptmate Technology Co., LTD

© Copyright Sep. 2010

Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties, with respect to the contents hereof, and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. The manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

Trademark Recognition

The product names mentioned in this compatibility test report are the properties of their respective owners and are acknowledged.

Office:

Address: 6F., No.5, Jian 1st Rd.,
Zhonghe City, Taipei County 235, Taiwan (R.O.C.)
Tel: +886-2-32342986
Fax: +886-2-32341128

Service Centers


Taiwan	sales@uptmate.com.tw
---------------	--

First of all, we are glad to introduce USP 1.0 to you. This document will help you to use this powerful scheduling program on UT-3610. Please enjoy it!


- Step 1: Click “USPv1.0 Beta” icon to execute USP
Click




- Step 2: Select On/Off to enable Auto Power On/Off Function



- Step 3: Select Start Time and End Time for Power On and Power Off Schedule



➤ Step 4: Select Holidays that do not want to operate




➤ Step 5: Set Time Zone Schedule and Volume (Default “All Time”)

Eg. Time Zone 1

Play Time: Start from 07:00 to 09:00

Volume: 08



➤ Step 6: Click “Apply”

➤ Step 7: Confirm to clear previous setting

It also supports timing setting and weekly setting.

Auto ON/OFF: ☒ ON ☐ OFF Holiday: **SUN SAT**

Start Time: 07:00 ☐ SUN ☐ MON ☐ TUE ☐ WED ☐ THU ☐ FRI ☒ SAT

End Time: 20:00

Scheduling

Warning


Add TimeZone 1 will remove the existing item with scheduling concern, Do you still want to apply?

是(Y) 否(N)


Apply Delete Time Zone

Time Zone	Start time	End time	Volume
All Time	07:00	20:00	00


- Step 8: Repeat Step 5 to Step 7
- Step 9: Click “Playlist” to edit Playlist




- Step 10: Browser the folder to select and add the content in Time Zone 1
And Click “Apply”!




➤ Step 11: Switch to Time Zone 2 and repeat Step 10




- Step 12: Save a “Project” and Enter the Project Name



- Step 13: Select a Card



➤ Step 14: Click “Write Data” to finish



Remark:

- UT-3610 must enable "Auto Play" in "Preference" Setting
- UT-3610 must enable "Repeat" Mode